



Low chemistry system R-T9

DEVELOPERS AND REPLENISHERS FOR THERMAL PLATES

DIRECT USE REPLENISHER FOR DEVELOPER IP-T9

LOW-CHEM SYSTEM

- ▶ The simultaneous use of the **Ipagsa plates, IP-T9** developer and replenisher **RT-9** form the “**Low Chem System**” of Ipagsa, providing significant advantages in reducing the volume of chemical used and recycled.
- ▶ Plates compatible with the “Low Chem System”: **Universe O₂**, **Universe HCR**, **Arte SF-25** and **Praxis TJ**.

PROPERTIES

- ▶ Maintains developer bath equilibrium between the developer components, buffer agents, antisepting and antifoaming agents, prolonging their action.
- ▶ Buffered product. Permits optimum replenishment of **DEVELOPER IP-T9**, with minimum consumption.

APPLICATION

- ▶ Replenishment in processors for thermal plates.
- ▶ Direct use.

METHOD OF USE

- ▶ Replenishment rate: 50 - 70 ml/m².
- ▶ Antioxidant Stand by ON: 40 - 60 ml/h.
- ▶ Antioxidant Stand by OFF: 40 - 60 ml/h.

CONSIDERATIONS

- ▶ Adequate replenishment keeps filters and circulation systems clean prolonging the life of the bath.
- ▶ Correct cleaning of the equipment will avoid contamination of the new bath and prolong the life of the processor. Clean using **PROCESSOR CLEANER PC-520** and **PROCESSOR CLEANER PC-600**.

PACKAGING

- ▶ 20 and 200 liters.
- ▶ Other packaging available on request.

Note:
The results obtained may vary depending if the conditions of use are outside of our recommended values